

18016

NICKLE ENGINEERING
NORMANBY
PH (06) 2728143

Specialists in multi axle Truck & Bus
Wheel Alignment & on board wheel balancing

We use WATKINS ALIGNMENT SYSTEMS methods proven
over thousands of alignments New Zealand wide

Name DOMMETS [FONTERRA]
Address _____
Telephone _____
Vehicle (VIN#) TRAILER
License F/N 2104
Mileage _____
Technician RD
Time and Date 12:24:48 09/09/08
Specifications TRAILER MULTI AXLE

Left Rear

Min.	Max.	Actual
.....	0.5°
.....	1.4mm

Camber
Toe

Right Rear

Actual	Min.	Max.
0.2°
1.2mm

Rear

Total Toe
Scrub Angle

Actual	Min.	Max.
2.6mm
0.01°	-0.02°	0.02°

Left Rear

Min.	Max.	Actual
.....	0.4°
.....	-0.2mm

Camber
Toe

Right Rear

Actual	Min.	Max.
0.2°
-0.2mm

Rear

Total Toe
Thrust Angle

Actual	Min.	Max.
-0.5mm
0.00°	-0.02°	0.02°

Left Rear

Min.	Max.	Actual
.....	0.6°
.....	0.3mm

Right Rear

Actual	Min.	Max.
0.4°
0.7mm

Camber
Toe

Rear

Total Toe
Scrub Angle

Actual	Min.	Max.
1.1mm
-0.01°	-0.02°	0.02°

Left Rear

Min.	Max.	Actual
.....	0.4°
.....	5.1mm

Right Rear

Actual	Min.	Max.
0.3°
-5.7mm

Camber
Toe


Rear

Total Toe
Thrust Angle


Actual	Min.	Max.
-0.7mm
0.36°	-0.02°	0.02°

Vehicle Adjustments

Separation:



0.19mm
Adjustment



Adjust rear scrub angle, then print summary.

Print
Screen


Identify
Customer

Inspect
Vehicle

HELP

Vehicle Adjustments

Separation:




0.61°

Scrub Angle

10.11mm

Adjustment



Adjust rear scrub angle, then print summary.

Print
Screen


Identify
Customer

Inspect
Vehicle

HELP

Vehicle Adjustments


Separation:



Thrust Angle

0.01mm

Adjustment



Adjust rear thrust angle, then press "Ready".

Print
Screen


Identify
Customer

Inspect
Vehicle

HELP

Vehicle Adjustments

Separation:




↓
-0.07°

Thrust Angle

↓
1.22mm

Adjustment



Adjust rear thrust angle, then press "Ready".

Print
Screen


Identify
Customer

Inspect
Vehicle

HELP

Vehicle Adjustments

Separation:




0.01°

Scrub Angle

0.08mm

Adjustment



Adjust rear scrub angle, then press "Ready".

Print
Screen


Identify
Customer

Inspect
Vehicle

HELP

Vehicle Adjustments

Separation:




0.34°

Scrub Angle

5.55mm

Adjustment



Adjust rear scrub angle, then press "Ready".

Print
Screen



Identify
Customer

Inspect
Vehicle

HELP

Vehicle Adjustments

Separation:




0.00°

Thrust Angle

0.00mm

Adjustment



Adjust rear thrust angle, then press "Ready".

Print
Screen


Identify
Customer

Inspect
Vehicle

HELP

Vehicle Adjustments

Separation:




0.27°

Thrust Angle

4.42mm

Adjustment



Adjust rear thrust angle, then press "Ready".

Print Screen	Identify Customer	Inspect Vehicle	HELP
--------------	-------------------	-----------------	------